

## IBM Hardware PRO Pack for Microsoft System Center Virtual Machine Manager User's Guide

Version 5.0



## IBM Hardware PRO Pack for Microsoft System Center Virtual Machine Manager User's Guide

Version 5.0

ote						<u> </u>
fore using this inf	formation and the p	product it suppor	ts, read the infor	mation in "Cop	yright notice" or	n page 29.

## **Edition notice**

This edition applies to version 5.0 of the IBM Hardware PRO Pack for Microsoft System Center Virtual Machine Manager, v5.0 User's Guide and to all subsequent releases and modifications until otherwise indicated in new editions.

© Copyright IBM Corporation 2012. US Government Users Restricted Rights – Use, duplication or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

## Contents

Figures v	Repairing and removing the IBM Hardware PRO Pack
Tables vii	File and registry locations
About this publication ix  Conventions and terminology ix  PDF files ix	Chapter 5. Working with the IBM Hardware PRO Pack
World Wide Web resources xi	Manager 2008 and Systems Center Operations  Manager
Chapter 1. IBM Hardware PRO Pack for Microsoft System Center Virtual  Machine Manager	Synchronizing System Center Virtual Machine Manager 2012 and Systems Center Operations Manager
Chapter 2. Configuring Operations Manager integration with System Center Virtual Machine Manager 5 Configuring the Hyper-V host	Chapter 6. Using Health Explorer to identify and resolve problems 23 Identifying and resolving a critical error
Chapter 4. Uninstalling the IBM Hardware PRO Pack	Index

© Copyright IBM Corp. 2012 iii

## **Figures**

	4 . 4 . 1 . 1 . 1						** .		
1.	Active alerts displayed.				. 16	6.	Host summary		22
2.	Available views				. 17	7.	Critical error for a managed host		24
3.	Host summary				. 19	8.	Error displayed in Health Explorer		25
4.	Detailed view of PRO .				. 20	9.	Error details		26
5	Host summary				21				

© Copyright IBM Corp. 2012 **V** 

_	
┰~	
	 _
- Lu	

© Copyright IBM Corp. 2012 vii

## About this publication

This book provides instructions for installing the IBM® Hardware PRO Pack for Microsoft System Center Virtual Machine Manager, Version 5.0 into Microsoft System Center Operations Manager 2007 or Microsoft System Center Operations Manager 2012, and for using the integrated features to manage systems in your environment.

## Conventions and terminology

These notices are designed to highlight key information.

**Note:** These notices provide important tips, guidance, or advice.

**Important:** These notices provide information or advice that might help you avoid inconvenient or difficult situations.

**Attention:** These notices indicate possible damage to programs, devices, or data. An attention notice is displayed before the instruction or situation in which damage can occur.

## **PDF** files

View or print documentation that is available in Portable Document Format (PDF).

## **Downloading Adobe Acrobat Reader**

You need Adobe Acrobat Reader to view or print these PDF files. You can download a copy from the Adobe website.

### Viewing and printing PDF files

You can view or print the following PDF files. The most current version of each document is available on the product download page. Go to the IBM website for Microsoft Systems Management Solutions for IBM servers at IBM System x<sup>®</sup> Integration Offerings for Microsoft Systems Management Solutions.

## World Wide Web resources

The following web pages provide resources for understanding, using, and troubleshooting IBM System x, IBM BladeCenter<sup>®</sup> blade servers, and systems-management tools.

## IBM website for Microsoft Systems Management Solutions for IBM servers

IBM website for Microsoft Systems Management Solutions for IBM servers: http://www-947.ibm.com/support/entry/portal/docdisplay?brand=5000016 &Indocid=SYST-MANAGE

Locate the latest product downloads available for the System Center Virtual Machine Manager for Microsoft System Center Virtual Machine Manager, v4.0 and linkage needed to purchase activation licenses per managed end point.

### **IBM Systems: Technical support site**

IBM Systems: Technical support site: http://www.ibm.com/systems/support/

Locate support for IBM hardware and systems-management software.

## **IBM Systems Management Software: Download/Registration**

IBM Systems Management Software: Download/Registration Page: http://www-03.ibm.com/systems/software/director/downloads/agents.html

Download IBM systems-management software, including IBM Systems Director.

#### IBM System x Systems Management

IBM System x Systems Management page: http://www.ibm.com/systems/management/

Obtain an overview of IBM systems management using IBM Director Agent or IBM Director Core Services.

#### IBM ServerProven®

For information about hardware compatibility with IBM System x, IBM BladeCenterIBM IntelliStation<sup>®</sup>, and hardware, refer to IBM ServerProven<sup>®</sup>.

### Microsoft System Center Virtual Machine Manager

Microsoft System Center Virtual Machine Manager TechCenter at http://technet.microsoft.com/en-us/scvmm/default.aspx.

Obtain information about System Center Virtual Machine Manager that describes how to manage the virtualized datacenter. SCVMM provides cross-platform support, Performance and Resource Optimization (PRO), and enhanced high availability (HA) capabilities.

## **Microsoft System Center Operations Manager**

Microsoft System Center Operations Manager TechCenter at http:// technet.microsoft.com/en-us/opsmgr/default.aspx

Obtain information about Systems Center Operations Manager that describes how to monitor your IBM systems across large organizations, using IBM and Microsoft applications and operating system knowledge to resolve operational problems.

# **Chapter 1. IBM Hardware PRO Pack for Microsoft System Center Virtual Machine Manager**

The IBM Hardware PRO Pack for Microsoft System Center Virtual Machine Manager, v5.0, provides performance and resource-optimization tips (PRO tips) that describe the hardware health state, alerting information, and virtual machine migration recommendations for the physical systems hosting Hyper-V and Virtual Server.

The IBM Hardware PRO Pack, v5.0 also provides monitoring and alerting information for IBM System x rack servers and IBM BladeCenter blade servers that are installed with IBM Director Core Services or IBM Director Agent.

## **Key features**

This topic explains the key features of the IBM Hardware PRO Pack for Microsoft System Center Virtual Machine Manager, v5.0.

Key features include:

- Detailed system health information for physical servers hosting virtual machines while managing Hyper-V or Virtual Server environments
- Comprehensive health state monitoring of physical processors, memory, hard disks, fans, power supplies, temperature and voltage on IBM System x and blade x86/x64 virtual host servers
- Advisory PRO tips about existing or potential hardware problems that warrant VMM administrative operations
- Automated VM Migration support based on hardware failures or exceptions to power consumption thresholds for uEFI/IMM System x Servers and Blades running Windows 2008 R2, Hyper-V or Virtual Server.

For more information about power consumption thresholds, refer to the Premium features topic in the Product information chapter for the *IBM Hardware Management Pack for Microsoft System Center Operations Manager*, v5.0 Installation and User's Guide.

**Note:** Automated VM Migration support based on power consumption threshold exceptions is supported only on uEFI/IMM System x Servers and Blades running Windows 2008 R2 and the IBM Director Platform Agent v6.2.1 and newer.

BladeCenter and Blade hardware health correlation and event propagation

**Important:** The IBM Hardware PRO Pack, v5.0 is a fee-based product component of the IBM Upward Integration for Microsoft System Center, v5.0 bundle. All features and usage of the IBM Hardware PRO Pack require the purchase and implementation of an activation license. Activation licenses can be purchased by contacting your IBM representative or IBM Business Partner.

## Microsoft System Center Virtual Machine Manager overview

Microsoft System Center Virtual Machine Manager is a comprehensive solution for virtualized data centers. SCVMM PRO combines the hardware health knowledge and monitoring capabilities built into Systems Center Operations Manager (SCOM) with the management services for the physical and virtual machines built into System Center Virtual Machine Manager (SCVMM).

This solution provides administrators with an extensible framework for monitoring the physical resources within their virtual environments.

SCVMM and SCOM servers maintain continuous communication through their respective agents to provide comprehensive health and performance information on the infrastructures that they manage. While SCOM is designed to collect, monitor, and assist the user in resolving health or performance problems on physical resources, SCVMM is designed to manage the virtualized workloads that can be affected by these types of condition changes. Alerts are displayed through the SCVMM console in the form of PRO tips. A PRO tip is a recommendation to help you place, migrate, or reconfigure applications, hardware, or virtual machines. These recommendations can then be implemented manually to return the workload to an optimal state.

## How IBM Hardware PRO Pack supports IBM systems

The IBM Hardware PRO Pack communicates with individual servers. These servers include BladeCenterblade servers that are running a Windows operating system supported by Hyper-V and Virtual Server with a supported version of IBM Director Core Services or IBM Director Agent installed.

## Supported systems

This topic lists the servers supported by IBM Hardware PRO Pack, v5.0.

The servers listed in Table 1 are supported by IBM Hardware PRO Pack, v5.0:

**Note:** Power monitoring support is available for the uEFI/IMM System x Servers and Blades denoted below with an asterisk (\*), running Windows 2008 R2 and the IBM Director Platform Agent v6.2.1 and newer only.

Table 1. Supported servers

Server product name	Machine type
IBM BladeCenter HS12	8014, 8028
IBM BladeCenter HS21	8853
IBM BladeCenter HS22	7870*
IBM BladeCenter HS22V	7871*
IBM BladeCenter HS23	7875*, 1929
IBM BladeCenter HS23E	8038, 8039
IBM BladeCenter HX5	7872*
IBM BladeCenter LS21	7971
IBM BladeCenter LS22	7901
IBM BladeCenter LS41	7972
IBM BladeCenter LS42	7902

Table 1. Supported servers (continued)

Server product name	Machine type
IBM Flex System <sup>™</sup> x220 Computer Node	7906, 2585
IBM Flex System x240 Computer Node	8737, 8738, 7863
IBM Flex System x440 Computer Node	7917
IBM NeXtScale Node	5455
IBM System x3250 M3	4251*, 4252*
IBM System x3250 M4	2583, 2587
IBM System x3250 M5	5458
IBM System x3300 M4	7382
IBM System x3350	4192
IBM System x3400 M3	7378*, 7379*
IBM System x3500 M3	7380*
IBM System x3500 M4	7383*
IBM System x3530 M4	7160
IBM System x3550	7978
IBM System x3550 M3	7944*
IBM System x3550 M4	7914*
IBM System x3620 M3	7376*
IBM System x3630 M3	7377*
IBM System x3630 M4	7158
IBM System x3650	7979
IBM System x3650 M3	7945*
IBM System x3650 M4	7915*
IBM System x3650 M4 BD	5466
IBM System x3690 X5	7147, 7148*
IBM System x3750 M4	8722, 8733, 8752
IBM System x3755	7163
IBM System x3755 M3	7164
IBM System x3850 M2	7141
IBM System x3850 X5	7145*
IBM System x3950 M2	7141
IBM System x3950 X5	7145*
IBM System x iDataPlex® dx360 M4	7912*, 7913*

## **Supported configuration**

This topic explains important configuration information.

Important: Installing and using the IBM Hardware PRO Pack for Microsoft System Center Virtual Machine Manager, v5.0 in an unlicensed environment is not supported. Doing so might cause unexpected results for all monitored hosts.

When moving from a licensed environment to an unlicensed environment it is strongly recommended that you uninstall the IBM Hardware PRO Pack for Microsoft System Center Virtual Machine Manager, v5.0.

## Installation requirements

This topic explains the software that must be installed on the management server to use the IBM Hardware PRO Pack.

Make sure that the following software is installed on the management server:

- For supporting System Center Virtual Machine Manager 2007, Microsoft System Center Operations Manager 2007 SP1, R2 are supported.
- For supporting System Center Virtual Machine Manager 2012, both Microsoft System Center Operations Manager 2007 and Microsoft System Center Operations Manager 2012 are supported.
- IBM Hardware Management Pack for Microsoft System Center Operations Manager, v5.0.
- Microsoft System Center Operations Manager 2012 SP1 and Microsoft System Center Virtual Machine Manager 2012 SP1 are both supported.

You can install the IBM Hardware PRO Pack, v5.0 on a Windows server that is running Microsoft System Center Operations Manager 2007 SP1, R2, 2012, or 2012 SP1.

**Note:** Verify that the system has enough disk space to perform this installation.

Microsoft System Center Operations Manager requirements are located on the Microsoft System Center Operations Manager website.

The IBM Hardware Management Pack installation and user's guide for v4.5 and v5.0 is located on the IBM System x Integration Offerings for Microsoft Systems Management Solutions website.

You can install Microsoft System Center Virtual Machine Manager 2008 R2, R2 SP1, or 2012 on the system that is running as a Microsoft System Center Operations Manager root management server, or on a system that is a dedicated Microsoft System Center Virtual Machine Manager server. The Microsoft System Center Virtual Machine Manager system requirements are located on the Microsoft System Center Virtual Machine Manager website.

**Important:** When importing the IBM Hardware PRO Pack Version 5.0, a connection to the management group must exist during the installation. To connect to the management group, you must be a member of the Operations Manager Administrators user role. Otherwise, you might encounter problems trying to import the IBM Hardware PRO Pack Version 5.0.

# **Chapter 2. Configuring Operations Manager integration with System Center Virtual Machine Manager**

The following Microsoft topic explains how to configure Microsoft System Center Operations Manager with Microsoft System Center Virtual Machine Manager.

For information, refer to Configuring Operations Manager Integration with VMM.

## **Configuring the Hyper-V host**

This topic lists information about configuring the Hyper-V host and refers you to additional information.

In order for the IBM Hardware PRO Pack to monitor the health of the physical host, one of the following versions of IBM Director Agent must be installed on the physical Hyper-V host:

- 6.1.2
- 6.2
- 6.2.1
- 6.3
- 6.3.1
- 6.3.2

For more information about software requirements for the host, refer to Virtualization with Hyper-V.

## Configuring Virtual Server 2008 R2 Enterprise Edition Support

This topic refers you to additional configuration information.

**Note:** System Center Virtual Machine Manager (SCVMM) 2012 no longer supports Virtual Server. The content that follows related to Virtual Server applies only to SCVMM 2007 R2 or R2 SP1.

For more information about software requirements for the host, refer to Microsoft Virtual Server.

## Chapter 3. Installing the IBM Hardware PRO Pack

Use this topic to help you install the IBM Hardware PRO Pack.

The integration of the IBM Hardware PRO Pack Version 5.0 into Microsoft's System Center Operations Manager enhances the management capabilities of IBM systems.

The IBM Hardware PRO Pack discovers IBM systems that host Hyper-V and virtual servers, and provides alerts about the health state of IBM System x and BladeCenter server systems.

## Downloading and installing IBM Hardware PRO Pack

Use the following steps to download and install the IBM Hardware PRO Pack, Version 5.0.

### Before you begin

For an Operations Manager Remote Management Server, install hot fixes applicable to both Windows server operating systems and Microsoft Operations Manager. For information about installing the hot fixes, see Support for running System Center Operations Manager 2007 Service Pack 1 and System Center Essentials 2007 Service Pack 1 on a Windows Server 2008-based computer

#### Procedure

Download IBM Hardware PRO Pack.

- Go to IBM System x Integration Offerings for Microsoft Systems Management Solutions and selectMicrosoft System Center Virtual Machine Manager. Refer to the content, excluding feature changes, in the IBM Hardware PRO Pack for Microsoft System Center Virtual Machine Manager, Version 5.0.
- 2. Under File Link, click **Sign in** to sign in with your IBM ID and password. The download page for IBM Director Upward Integration Modules (UIMs) is displayed.
- 3. Click the **Download Director** or the **Http** tab to download the files using your preferred download method. To download using the Download Director Java<sup>™</sup> application: In the IBM Director Upward Integration Modules for Microsoft section, select the check box for the appropriate download package for IBM Hardware PRO Pack Version 5.0 for Microsoft System Center Virtual Machine Manager.

Version 5.0 (32-bit and 64-bit):

ibm\_hw\_propack\_v5.0.xx\_setup.exe

Where *xx* in the name is an internal IBM tracking number.

- a. Scroll to the bottom of the page and select the check box to accept the license agreement. Then click I confirm to begin downloading the IBM Hardware PRO Pack, Version 5.0 installation package appropriate for your Microsoft System Center Operations ManagerServer to a temporary directory.
- b. On the Security dialog window that asks if you want to run the application, click **Run**

© Copyright IBM Corp. 2012 7

**c**. When the download completes, click **Close** [x] to close the download dialog window.

#### 4. Click OK.

**Note:** The installer checks for prerequisites. If the installer cannot find all of the prerequisites, a message box is displayed that indicates which prerequisites cannot be found.

The installer also checks if there is a previous version of IBM Hardware PRO Pack installed. If a previous version is detected, an informative message is displayed informing you that this version is not supported for an upgrade by this installer. A manual deletion of the previous PRO management pack from the Operations Manager is required. For more information on how to delete management packs from Operations Manager, refer to Operations Manager's documentation.

The Welcome to the InstallShield Wizard for IBM Hardware PRO Pack Version 5.0 for Microsoft System Center Virtual Machine Manager window is displayed.

**Note:** Before installing the IBM Hardware PRO Pack version 5.0 on a non-RMS server, make sure the required IBM Hardware Management Pack, v5.0 is installed on the non-RMS server. If the installer cannot find the required IBM Hardware Management Pack, v4.0, the installer stops.

- 5. Click **Next**. The License Agreement window is displayed.
- 6. Read the software license agreement. If you agree with the terms, select I accept the terms in the license agreement and click Next. If the system already has version 5.0 installed, you can select to repair or remove the IBM Hardware Management Pack, version 4.0. See the "Repairing and removing the IBM Hardware PRO Pack" on page 11 topic for more information.
- 7. Verify the default target location. If necessary, select the target folder for the installation code.
- 8. Click **Next**. The Import IBM Hardware PRO Pack v5.0 Management Pack window is displayed. This window reminds you to import the IBM Hardware PRO Pack management pack into the Systems Center Operations Manager console.

**Note:** For instructions on how to import, open the Systems Center Operations Manager console, select **Administrator**, and then select **Import Management Pack**.

- 9. To begin the installation, click **Next**.
- 10. When the installation is complete, read the reminder and click **Finish**.
- 11. Open the Operations Console of the Microsoft Systems Center Operations Manager.
- 12. On the Operations Console, click **Administration** > **Management Packs** > **Import Management Pack** to import the IBM Hardware PRO Pack. This import process completes the installation.

**Note:** The IBM Hardware PRO Pack management pack is located in the installation directory.

After selecting to import the IBM Hardware PRO Pack management pack, the following message is displayed: One or more Management Packs present a security risk. Are you sure you want to continue?

This message is considered normal behavior for the IBM Hardware PRO Pack because the IBM Hardware PRO Pack is sending event messages between the management server and the host system.

- 13. Click Yes.
- 14. Verify that the IBM Hardware PRO Pack import was successful by ensuring that the "IBM Hardware PRO Pack v5.0 for IBM System x and BladeCenter x Blade Servers" management pack appears in the Administration > Management Packs view.

#### Note:

- Sometimes management pack entries do not display immediately after the installation. Refresh the window or wait a few minutes until the management pack entry is displayed.
- The installation or uninstallation of the IBM Hardware PRO Pack can also be executed by using the IBM Upward Integration for Microsoft System Center Installer. Refer to the IBM Upward Integration for Microsoft System Center Integrated Installer User's Guide for more information on how to perform this action.

## Chapter 4. Uninstalling the IBM Hardware PRO Pack

To uninstall the IBM Hardware PRO Pack, use either Add or Remove Programs or Programs and Features.

## **Uninstalling the IBM Hardware PRO Pack**

#### **Procedure**

1. To completely uninstall the software package and related files, on the Windows Control Panel, select either **Add or Remove Programs** or **Programs and Features** .

Note: These programs silently remove the installed files.

 Select IBM Hardware PRO Pack for Microsoft System Center Virtual Machine Manager, v5.0, and select Uninstall at the top of the panel. You can also right-click on IBM Hardware PRO Pack for Microsoft System Center Virtual Machine Manager, v5.0 and select Uninstall.

**Note:** The process of uninstalling the IBM Hardware PRO Pack begins.

 To complete the uninstallation, open the Operations Manager console, click Administration > Management Packs, select the manage pack, and manually delete it.

**Note:** You can also either install or uninstall the IBM Hardware PRO Pack easily by using the IBM Upward Integration for Microsoft System Center Integrated Installer. Refer to the IBM Upward Integration for Microsoft System Center Integrated Installer User's Guide for more information on how to perform this action.

## Repairing and removing the IBM Hardware PRO Pack

#### About this task

The Repair function reinstalls the program and registry entries on the local server.

The Remove function uninstalls the IBM Hardware PRO Pack package from the local system, but does not delete the management pack from the Operations Manager console. You must use the Operations Manager console to delete the management pack from the Operations Manager.

## File and registry locations

This topic provides details about the default installation directory and registry path for the IBM Hardware PRO Pack, v5.0.

By default, the installation files for IBM Hardware PRO Pack, v5.0 are placed in the following directory:

%ProgramFiles%\IBM\IBM Hardware PRO Pack

The registry path for the IBM Hardware PRO Pack, v5.0 entry is:

## Reinstalling the IBM Hardware PRO Pack

If you recently removed management packs from the Microsoft System Center Operations Manager console and you want to reinstall the IBM Hardware PRO Pack, wait at least 30 minutes for the settings to propagate to the Operations Manager database before reinstalling the application. If you do not wait for the removal of the management pack to register, reinstalling can result in managed clients that are not listed in the Operations Manager console.

For more information about this known Microsoft System Center Operations Manager limitation, see the article Discovery information is missing after you delete and then reimport a management pack in Microsoft System Center Operations Manager.

When you delete the management packs from the console, you detach the IBM Hardware PRO Pack from the Operations Manager server. You must then import the IBM Hardware PRO Pack into Microsoft System Center Operations Manager to add the management pack back into the console view.

## **Chapter 5. Working with the IBM Hardware PRO Pack**

The topics in this chapter describe how to use the IBM Hardware PRO Pack.

The IBM Hardware PRO Pack enhances the functionality of both the Systems Center Operations Manager and the System Center Virtual Machine Manager to provide detailed information about managed Hyper-V and Virtual Server, IBM System x hardware.

**Note:** System Center Virtual Machine Manager (SCVMM) 2012 no longer supports Virtual Server.

After you have installed the IBM Hardware PRO Pack, use the following tasks to learn more about using the Systems Center Operations Manager and System Center Virtual Machine Manager. You can also refer to the Monitoring page of the Operations Manager console as described in the topic "Using the Operations Manager console with the IBM Hardware PRO Pack" on page 16 for more information about SCOM and SCVMM.

- Monitor the health of systems and components, as described in the "Monitoring the health of systems and hardware components" on page 14 topic.
- Identify and resolve errors, as described in the Chapter 6, "Using Health Explorer to identify and resolve problems," on page 23 topic.

# Synchronizing System Center Virtual Machine Manager 2008 and Systems Center Operations Manager

This topic provides the commands to use to synchronize System Center Virtual Machine Manager 2008 and Systems Center Operations Manager.

#### About this task

**Important:** When importing the IBM Hardware PRO Pack Version 5.0, a connection to the management group must exist during the installation. To connect to the management group, you must be a member of the Operations Manager Administrators user role. Otherwise, you might encounter problems trying to import the IBM Hardware PRO Pack.

#### **Procedure**

- 1. On your SCVMM management server, open a Windows PowerShell window.
- 2. On the command line, enter the following commands: get-vmmserver <fully qualified domain name of management server> set-vmmserver -opsmgrserver <fully qualified domain name of management server> For more information about using Windows PowerShell and the set-vmmserver command, refer to Microsoft documentation.

# Synchronizing System Center Virtual Machine Manager 2012 and Systems Center Operations Manager

This topic provides the commands to use to synchronize System Center Virtual Machine Manager 2012 and Systems Center Operations Manager.

#### About this task

**Important:** When importing the IBM Hardware PRO Pack Version 5.0, a connection to the management group must exist during the installation. To connect to the management group, you must be a member of the Operations Manager Administrators user role. Otherwise, you might encounter problems trying to import the IBM Hardware PRO Pack.

#### **Procedure**

- 1. On your SCVMM management server, open a Windows PowerShell window.
- 2. On the command line, enter the following commands:
  - a. Test-SCPROTip

This command creates a test PRO Tip, which is a roundtrip test that checks whether the VMM to Operations Manager integration is set up correctly to receive PRO Tips.

### b. Write-SCOpsMgrConnection

This command pushes all the objects that were previously undiscovered to Operations Manager. The discovery refresher runs every 6 hours in VMM to push objects to Operations Manager at regular intervals.

## **IBM Hardware PRO Pack host discovery**

This topic explains host discovery—the amount of time it takes for an IBM system to be displayed in the Licensed SCVMM-Managed Hosts Status view after the installation of IBM Hardware PRO Pack. IBM Hardware PRO Pack host.

After installation, it might take two or more minutes for an IBM system to show up in the IBM SCVMM-Managed Licensed Hosts (PRO Views) > Licensed SCVMM-Managed Hosts Status view. The time for all hardware components to be discovered and to start indicating their health state can take five minutes or longer.

Latency is determined by multiple influences:

- The number of managed systems in the discovery task
- The performance of the Operations Manager database
- The amount and speed of network traffic

**Note:** Latency for discovery is normal behavior for Microsoft System Center Operations Manager. However, you can override the default monitoring interval values to set a shorter interval.

For more information about overriding the default monitoring intervals, view the online help by clicking Resources > System Center Operations Manager Help.

## Monitoring the health of systems and hardware components

This topic explains what the IBM Hardware PRO Pack monitors and the steps you need to take to facilitate monitoring.

#### About this task

The IBM Hardware PRO Pack, v5.0 discovers and monitors only the following hardware health components of a Microsoft virtual machine host:

Processors

- Memory
- Network adapters
- Storage
- Management controllers
- Power supplies
- Fans
- Temperature sensors
- Voltage sensors
- Power<sup>®</sup> usage sensors

For best practices, use the IBM Hardware Management Pack to verify that all of the necessary management software is installed on all managed hosts.

Note: IBM Hardware PRO Pack health state reporting is limited to the components listed above only, and requires that all dependencies are met and functioning properly.

Component discovery and health monitoring depend on firmware support, hardware compatibility, and management software support. Because of the various factors involved, not all components are always discoverable. If a component is not discovered, it cannot be monitored or managed.

There are three locations where you can monitor system health with the IBM Hardware PRO Pack:

- Systems Center Operations Manager console
- System Center Virtual Machine Manager
- Applications Event log

#### **Procedure**

- 1. On the Systems Center Operations Manager console navigation panel, click Monitoring.
- 2. Expand the IBM SCVMM-Managed Licensed Hosts (PRO Views) folder. It contains the folders and views that the IBM Hardware PRO Pack adds to the Operations Manager console.
- 3. To view any critical or warning alerts associated with your IBM hardware, click Active PRO Alerts. The following image depicts how active alerts might be displayed:




Figure 1. Active alerts displayed

4. To view the status and health of your IBM systems' hardware, expand the IBM SCVMM-Managed Licensed Hosts (PRO Views) folder.

## Using the Operations Manager console with the IBM Hardware PRO Pack

This topic provides the steps for using the Operations Manager console with the IBM Hardware PRO Pack.

#### About this task

After installing the IBM Hardware PRO Pack, use the Monitoring page in the Operations Manager console to monitor systems. The IBM SCVMM-Managed Licensed Hosts (PRO Views) folder and views on the Monitoring page provide a complete view of the health of your PRO-Enabled Hyper-V and Virtual Server IBM System x hardware.

To see what the IBM Hardware PRO Pack adds, perform the following procedure to become familiar with the Monitoring page of the Operations Manager console.

#### **Procedure**

1. On the left panel of the Operations Manager console, click **Monitoring**.

2. Open the IBM SCVMM-Managed Licensed Hosts (PRO Views) folder. This folder includes Active PRO Alerts, task status, and the view for all discovered PRO-enabled virtual server and Hyper-V System x hardware.




Figure 2. Available views

The IBM Hardware PRO Pack adds the following views:

#### Active PRO alerts

The Active PRO Alerts window provides a state view of alerts for all discovered and PRO-enabled virtual server and Hyper-V IBM System x hardware.

**Note:** Alert text for many events is generic and might cover multiple events affecting the same hardware component. For more detailed alert information, see Chapter 6. Using Health Explorer to identify and resolve problems.

#### IBM SCVMM-Managed Licensed Hosts (PRO Views)

IBM SCVMM-Managed Licensed Hosts (PRO Views) is a state view of all discovered PRO-enabled virtual server and Hyper-V IBM systems. Use this view in the same way you use the **Monitoring** > **Computers** view. The difference between the two views is that the SCVMM-Managed Licensed Hosts (PRO Views) view contains only computers that are PRO-enabled, running Virtual Server or Hyper-V, and are on IBM System x hardware.

Note:

- If you are removing a managed client from the operations console, remove
  the client from the VMM as well. Otherwise, the client is grayed out under
  the Licensed SCVMM-Managed Host PRO Status from Operation Console.
- If you are upgrading the IBM Director Agent from an older version (for example, from 6.2.1 to 6.3) on a target server, remove and re-install the PRO Pack, restart the SCOM services, and follow the instructions in synchronize the SCVMM 2008 and SCOM servers or synchronize the SCVMM 2012 and SCOM servers based on your SCVMM version. Otherwise, the older version of the director agent entry may still show under the Licensed SCVMM-Managed Host PRO Status from Operations Console.

#### Task status

Task Status is the state view of all discovered and PRO-enabled virtual server and Hyper-V IBM System x hardware.

## Viewing alerts in System Center Virtual Machine Manager

This topic describes how to view alerts in System Center Virtual Machine Manager.

You can view alerts in System Center Virtual Machine Manager from either the main console page or from the PRO Tip view.

## Viewing alerts from the main console page for SCVMM 2008

This topic shows describes how to view alerts from the main console page for SCVMM 2008.

#### **Procedure**

- 1. In the navigation panel, click **Jobs**.
- 2. Locate jobs with the name **Set State of a PRO Tip**, or with a result name that starts with either **IBM HW PRO Pack Alert** or **IBM Hardware PRO Pack Alert**.

**Note:** If **Automatically implement PRO Tips** for this host group is checked on the PRO tab in the properties for **Hosts** > **All Hosts** > **group\_name**, all PRO tips in this view will be displayed as resolved even if an alert is active.




Figure 3. Host summary

## Viewing alerts from the main console page for SCVMM 2012

This topic describes how to view alerts from the main console page for SCVMM 2012.

#### **Procedure**

- 1. In the navigation panel, click VMs and Services.
- 2. Right-click the client machine and then click **Properties**.
- 3. On the Properties window, click **PRO State**. The detail view of PRO is displayed on the right side of the window.




Figure 4. Detailed view of PRO

### Viewing alerts from the PRO Tips view for SCVMM 2008

This topic describes how to view alerts from the PRO Tips view for SCVMM 2008.

### **Procedure**

1. On the horizontal toolbar, click **PRO Tips**. Any active alerts are displayed here.

**Note:** If **Automatically implement PRO Tips on this Host Group** is selected on the PRO tab in the properties for **Hosts** > **All Hosts** > **group\_name**, you will see PRO Tips in this view as "resolved" even if an alert is active.




Figure 5. Host summary

From the server manager, expand Diagnostics > Event Viewer > Windows
 Logs > Application. The IBM Hardware PRO Pack events are displayed with a
 source of VMM PRO.

#### What to do next

Learn how to use the Health Explorer to identify, examine, and resolve critical problems. See Chapter 6, "Using Health Explorer to identify and resolve problems," on page 23 for more information.

#### Viewing alerts from the PRO Tips view for SCVMM 2012

This topic shows how to view alerts from the PRO Tips view for SCVMM 2012.

#### **Procedure**

On the horizontal toolbar, click PRO Tips. Any active alerts are displayed here.

**Note:** In some cases, text may not display completely in the PRO tip window. To show all the text, maximize the PRO tip window.




Figure 6. Host summary

## Viewing alerts from servers

You can use Microsoft System Center Operations Manager to view alerts that are sent from appropriately configured PRO-enabled virtual servers and Hyper-V IBM System x hardware.

#### About this task

Ater a PRO Tip is implemented, the IBM Hardware PRO Pack,v5.0 automatically resets the health status. However, dismissed or cancelled PRO Tips require you to manually reset the health status to the normal health state of components after the condition or problem has been investigated and resolved.

To view the alerts for a system, complete the following steps.

#### **Procedure**

- 1. Navigate to Monitoring > IBM SCVMM-Managed Licensed Hosts (PRO Views) > Licensed SCVMM-Managed Hosts Status.
- 2. Right-click on a server to open views for monitoring. You can monitor alerts by using the Alert View, Diagram View, Event View, and State View.

# **Chapter 6. Using Health Explorer to identify and resolve problems**

You can use the Health Explorer to identify and resolve error states that are displayed when monitoring IBM systems and hardware components.

For a quick view of the status, look at Active PRO Alerts or IBM SCVMM-Managed Licensed Hosts (PRO Views). These views show any existing alerts on your IBM hardware.

**Note:** Alert text for many events is generic and might cover multiple events affecting the same hardware component.

Use the Health Explorer to view, learn about, and act on alerts, state changes, and other issues that occur for the monitored object. The following image depicts how a critical error is displayed for a managed host.

© Copyright IBM Corp. 2012




Figure 7. Critical error for a managed host

## Identifying and resolving a critical error

Use the Health Explorer to identify and resolve error states that are displayed when monitoring IBM systems and hardware components.

#### About this task

To identify and resolve the critical error, complete the following steps.

#### **Procedure**

- Open the Health Explorer by navigating to Monitoring > SCVMM > IBM SCVMM-Managed Licensed Hosts (PRO Views).
- 2. Double-click the state. By default, the Health Explorer opens with all failed monitors in an expanded view.

The following image shows how an error might be displayed in the Health Explorer:




Figure 8. Error displayed in Health Explorer

**Note:** If there is no warning or critical alert, select and right-click on the IBM system in the IBM SCVMM-Managed Licensed Hosts (PRO Views) view to show its context menu. Click **Open** and click **Health Explorer for system name**.

- 3. Identify the basal-level health monitor that is indicating an error. The indication should refer to a particular component instance.
  - In the example image below, the cause of the error is a power usage setting that is higher than the critical power threshold.
- 4. To resolve the error, manually complete the steps listed in the Resolutions section.
- 5. On the right panel, click **State Change Events** for details about the latest state change event.

You can see the date and the time that the fan entered the error state. You can also read details about the error.




Figure 9. Error details

#### What to do next

For details on accessing and using the IBM knowledge pages, check the IBM Hardware Management Pack for Microsoft System Center Operations Manager, v5.0 documentation.

# Appendix. References

These topics contain additional reference information to help you.

### Accessibility for IBM Hardware PRO Pack

Accessibility features help users who have a disability, such as restricted mobility or limited vision, to use information technology products successfully.

IBM strives to provide products with usability access for everyone, regardless of age or ability.

### **Accessibility features**

For specific information about accessibility features and keyboard navigation, refer to the Microsoft System Center Virtual Machine Manager software documentation.

The following list includes the major accessibility features in IBM System Updates:

- · Can be operated using only the keyboard
- · Communicates all information independent of color
- · Inherit system settings for font, size, and color
- Supports interfaces commonly used by screen readers and screen magnifiers

You can view the publications for IBM Hardware PRO Pack for Microsoft System Center Virtual Machine Manager, Version 5.0 in Adobe Portable Document Format (PDF) using the Adobe Acrobat Reader. You can access the PDFs from the IBM Hardware PRO Pack, v5.0 download site.

## **Keyboard navigation**

This product uses standard Microsoft® Windows navigation keys.

#### IBM and accessibility

For information about the commitment that IBM has to accessibility, see the IBM Human Ability and Accessibility Center .

© Copyright IBM Corp. 2012 27

# Copyright notice and trademarks

### Copyright notice

This information was developed for products and services offered in the U.S.A.

IBM may not offer the products, services, or features discussed in this document in other countries. Consult your local IBM representative for information about the products and services currently available in your area. Any reference to an IBM product, program, or service is not intended to state or imply that only that IBM product, program, or service may be used.

Any functionally equivalent product, program, or service that does not infringe any IBM intellectual property right may be used instead. However, it is the user's responsibility to evaluate and verify the operation of any non-IBM product, program, or service.

IBM may have patents or pending patent applications covering subject matter described in this document. The furnishing of this document does not grant you any license to these patents. You can send license inquiries, in writing, to:

IBM Director of Licensing

**IBM Corporation** 

North Castle Drive

Armonk, NY 10504-1785

U.S.A.

For license inquiries regarding double-byte (DBCS) information, contact the IBM Intellectual Property Department in your country or send inquiries, in writing, to:

IBM World Trade Asia Corporation Licensing

2-31 Roppongi 3-chome, Minato-ku

Tokyo 106-0032, Japan

The following paragraph does not apply to the United Kingdom or any other country where such provisions are inconsistent with local law:

INTERNATIONAL BUSINESS MACHINES CORPORATION PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

Some states do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

© Copyright IBM Corp. 2012

This information could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. IBM may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time without notice.

Any references in this information to non-IBM web sites are provided for convenience only and do not in any manner serve as an endorsement of those web sites. The materials at those web sites are not part of the materials for this IBM product and use of those web sites is at your own risk.

IBM may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you.

Licensees of this program who wish to have information about it for the purpose of enabling: (i) the exchange of information between independently created programs and other programs (including this one) and (ii) the mutual use of the information which has been exchanged, should contact:

**IBM Corporation** 

MW9A/050

5600 Cottle Road

San Jose, CA 95193

U.S.A.

Such information may be available, subject to appropriate terms and conditions, including in some cases, payment of a fee.

The licensed program described in this document and all licensed material available for it are provided by IBM under terms of the IBM Customer Agreement, IBM International Program License Agreement or any equivalent agreement between us.

Any performance data contained herein was determined in a controlled environment. Therefore, the results obtained in other operating environments may vary significantly. Some measurements may have been made on development-level systems and there is no guarantee that these measurements will be the same on generally available systems. Furthermore, some measurements may have been estimated through extrapolation.

Actual results may vary. Users of this document should verify the applicable data for their specific environment.

Information concerning non-IBM products was obtained from the suppliers of those products, their published announcements or other publicly available sources. IBM has not tested those products and cannot confirm the accuracy of performance, compatibility or any other claims related to non-IBM products. Questions on the capabilities of non-IBM products should be addressed to the suppliers of those products.

This information contains examples of data and reports used in daily business operations. To illustrate them as completely as possible, the examples include the

names of individuals, companies, brands, and products. All of these names are fictitious and any similarity to the names and addresses used by an actual business enterprise is entirely coincidental.

If you are viewing this information softcopy, the photographs and color illustrations may not appear.

#### **Trademarks**

IBM, the IBM logo, and ibm.com® are trademarks or registered trademarks of International Business Machines Corporation in the United States, other countries, or both. If these and other IBM trademarked terms are marked on their first occurrence in this information with a trademark symbol (or), these symbols indicate U.S. registered or common law trademarks owned by IBM at the time this information was published. Such trademarks may also be registered or common law trademarks in other countries. A current list of IBM trademarks is available on the web at "Copyright and trademark information" at http://www.ibm.com/legal/copytrade.shtml.

Adobe, Acrobat, and Portable Document Format (PDF) are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States, other countries, or both.

Intel<sup>®</sup>, Itanium<sup>®</sup>, and Pentium<sup>®</sup> are trademarks of Intel Corporation in the United States, other countries, or both.

Microsoft and Windows are trademarks of Microsoft Corporation in the United States, other countries, or both.

Other company, product, or service names may be trademarks or service marks of others.

# Index

# Ν

notices 29

### T

trademarks 29

© Copyright IBM Corp. 2012

### Readers' Comments — We'd Like to Hear from You

IBM System x IBM Hardware PRO Pack for Microsoft System Center Virtual Machine Manager User's Guide Version 5.0

We appreciate your comments about this publication. Please comment on specific errors or omissions, accuracy, organization, subject matter, or completeness of this book. The comments you send should pertain to only the information in this manual or product and the way in which the information is presented.

For technical questions and information about products and prices, please contact your IBM branch office, your IBM business partner, or your authorized remarketer.

When you send comments to IBM, you grant IBM a nonexclusive right to use or distribute your comments in any way it believes appropriate without incurring any obligation to you. IBM or any other organizations will only use the personal information that you supply to contact you about the issues that you state on this form.

Comments:

Thank you for your support.		
Send your comments to the address on the 1	everse side of this form.	
If you would like a response from IBM, plea		
Name	Address	
Company or Organization		
Phone No	Email address	

Cut or Fold Along Line

Fold and Tape

Please do not staple

Fold and Tape



NO POSTAGE NECESSARY IF MAILED IN THE UNITED STATES

# **BUSINESS REPLY MAIL**

FIRST-CLASS MAIL PERMIT NO. 40 ARMONK, NEW YORK

POSTAGE WILL BE PAID BY ADDRESSEE

International Business Machines Corporation PO Box 12195 Research Triangle Park NC U.S.A. 27709-9990



Tabiliadhadhaddaddaddadhadadd

Fold and Tape

Please do not staple

Fold and Tape

# IBM

Printed in USA